





















Assembly Instruction Sheet

CAUTION: Because of the edges of some parts before assembly may be sharp, please handle unassembled parts carefully.



partslist	Qty
A 	1PC
B 	1PC
C 	1PC
D 	1PC
E 	1PC
F 	1PC
G 	5PCS
H M6*35mm 	6PCS
I M6*30mm 	4PCS
J M8*20mm 	3PCS
L M8*ø17 	3PCS
M M8*ø14*2mm 	3PCS
N M6*ø14 	6PCS
O M6 	1PC



Never wave or bump the chair fiercely.
Never wipe with damp cloth or hard things.
Stock in door after cleaning when not used.

sømcasa