

Care Guide Furniture



**A little care goes
a long way.**



Essential tips for protecting your noo.ma products.

Please review them before first use.

- Avoid placing the furniture in direct sunlight or near a strong heat source to reduce changes.
- Avoid improper use such as putting your feet and standing on the table or sitting on the sideboards.
- Be careful not to scratch or damage the surface with sharp objects.
- Always remove stains quickly before they can cause any permanent damage to the furniture.
- When moving your furniture, make sure to lift it to avoid damaging the floor, legs and mountings.
- Use protective mats under pots or hot objects.

Wooden/Veneer parts

Wood is a natural material – all veins and small knots are part of its character. All wooden/veneer elements must only be cleaned using lukewarm water and a mild detergent like soap, then wiped dry.

Please keep in mind the following care tips to maintain the quality and appearance of veneer surfaces:

- Never place hot objects, such as tealights or pots, directly on the wooden surface: temperatures above 50°C may leave marks, cause cracking or the veneer to detach from its core.
- Veneered surfaces made from natural wood will naturally change in tone over time. These changes are accelerated by UV exposure and vary depending on its intensity.
- Avoid exposing veneered panels or elements to excessive moisture. Too much water can lead to swelling, delamination, and veneer cracking.
- Keep the surface away from solvents, ammonia, corrosive substances, and strongly staining liquids.

Fabrics

Most stains can be removed with water and a mild detergent like soap. Always dab gently – do not scratch or rub the material, and avoid spot cleaning individual marks, as this may cause damage or discoloration.

To keep your fabrics looking fresh, we recommend the following care:

- Vacuum occasionally using the upholstery nozzle to remove dust and prevent fluff and pilling.
- To avoid wrinkles, straighten the fabric with your hands from time to time.
- Soak up spilled liquids immediately using an absorbent napkin or cloth by dabbing gently toward the center of the stain.
- Use only neutral detergents when necessary. Avoid using harsh chemicals. A hairdryer can help prevent watermarks after cleaning.
- If the stain persists or is likely to leave a mark (e.g. red wine), consult a specialist cleaner.

Glass

Our structured glass fronts can be cleaned using standard glass cleaning products or a mild detergent like soap and lukewarm water. Always dry the surface with a soft, clean cloth to avoid streaks or water spots. Do not scratch or damage the glass with hard, sharp, or pointed objects.

Melaminized boards

When cleaning is required we recommend a soft, damp cloth and water. If a detergent is needed it should be a mild one like soap or washing-up liquid. Always avoid using detergents that contain alcohol and ammonia or ones that have an abrasive or bleaching effect. When using soap or washing-up liquid, wipe it clean with water and wipe dry immediately. This is to avoid water remaining on the surface.

Powder coated steel elements

Our powder coated steel parts should be cleaned using water and a mild detergent, such as soap, and then wiped dry with a soft cloth.

Please note the following care recommendations:

- Clean only with gentle, non-abrasive cleaning agents.
- Avoid any contact with solvents, ammonia, corrosive substances, or strongly staining liquids, as they may damage the surface.
- Unless otherwise specified, powder coated steel products are not suitable for outdoor use.